

BRASSLUX

ARTISAN LUXURY FIXTURES

SOLID BRASS BATHTUB INSTALLATION & CARE

PRE-INSTALLATION ESSENTIALS

- **Inspection:** Unpack and inspect the item for any shipping damages. If any issues are found, do not install and contact customer support immediately.
- **Professional Installation:** We strongly recommend hiring a licensed professional for the installation of this luxury fixture.
- **Code Compliance:** Ensure your installation complies with all local plumbing and building regulations.
- **Handcrafted Variation:** Due to the artisanal manufacturing process, minor dimensional variations are a hallmark of our handmade tubs.

INSTALLATION STEPS

01. **Marking:** Position the tub in its intended location and mark the drain centerline on the floor.
02. **Plumbing:** Install rough plumbing; the tailpiece should extend approximately 6" above the finished floor.
03. **Leveling:** Place the tub in its final position. Use leveling feet or shims to ensure it is perfectly level.
04. **Sealing:** Apply 100% neutral cure silicone or plumbers' putty under the drain flange for a secure seal.
05. **Testing:** Fill the tub to verify there are no leaks in the tailpiece or P-trap connections.

CARE & MAINTENANCE

The Dos:

- Apply a high-quality wax coating regularly to protect the living finish.
- Clean with mild dish soap and warm water only.
- Dry with a soft microfiber cloth after each use to prevent water spots.

The Don'ts:

- **No Abrasives:** Never use steel wool or harsh scouring pads.

- **No Acids:** Avoid vinegar, lemon, or acidic cleaners which will strip the patina.
- **No Salts:** Do not use Epsom or bath salts as they can corrode the copper.