

# Installation steps

## Step 2

Before the installation to confirm the water is not all can be discharged, leaving the floor next to the tile, a good size to cut.



## Step 3

When cutting more than a little gap.



## Step 3

To brush the cement on the floor drain back, let it and the ground adhesion.



## Step 4

Place the drain at the center of the drain pipe and place it in the piece and press it in parallel with the tile.



## Step 5

Clean up the ground and floor drain.



## Step 6

Install the filter after the cement is dry.



## Step 6

Install the filter after the cement is dry.